



- 1820 West 200 South
Lindon, UT 84042
- (801) 922-4700
(888) 499-8494 Toll Free
- www.interstategratings.com

How to Specify Aluminum Bar Grating

1. Select type of grating
 - "ADT" for Aluminum Dovetail Pressure Locked Grating
 - "SG" for Swaged Rectangular Bar Grating
 - "SGI" for Swaged "I-Bar" Grating
2. Select bar spacing from the Aluminum Bar Grating Table of Spacings
3. Select bar size (consult load tables considering service loads and clear spans)
4. Specify Plain or Serrated surface
5. Specify banding or additional trim required
6. Specify finish
 - Mill Finish (no finish)
 - Anodized (clear, bronze, other)
 - Powder Coating
 - Other
7. Specify fasteners (if required)

Our team of grating experts is available to answer any questions you may have on specifying aluminum bar grating.

(888) 499-8494

sales@interstategratings.com