



- 1820 West 200 South
Lindon, UT 84042
- (801) 922-4700
(888) 499-8494
- www.interstategratings.com

How to Specify Stainless Steel Bar Grating

1. Select type of grating
 - a. **"WS"** for Welded Stainless Steel Grating
 - b. **"DTS"** for Dovetail Pressure Locked Stainless Grating
2. Select bar spacing from Stainless Steel Grating Table of Spacings
3. Select bar size (consult load tables considering service loads and clear spans)
4. Specify Plain or Serrated surface
5. Specify banding or additional trim required
6. Specify finish
 - a. Mill finish
 - b. IG EcoClean™
7. Specify fasteners (if required)

Our team of grating experts is available to answer any questions you may have on specifying stainless steel bar grating.

(888) 499-8494

sales@interstategratings.com