



- 1820 West 200 South
Lindon, UT 84042
- (801) 922-4700
(888) 499-8494 Toll Free
- www.interstategratings.com

How to Specify Steel Bar Grating

1. Select type of grating
 - "W" for Welded Steel Grating
 - "DT" for Dovetail Pressure Locked Grating
 - "SL" for Swage Locked Grating
2. Select bar spacing from the Steel Bar Grating Table of Spacings
3. Select bar size (consult load tables considering service loads and clear spans)
4. Specify Plain or Serrated surface
5. Specify banding or additional trim required
6. Specify finish
 - Bare steel (no finish)
 - IG EcoCoat™ - Standard Black
 - Hot Dip Galvanized (per ASTM A-123)
 - Other
7. Specify fasteners (if required)

Our team of grating experts is available to answer any questions you may have on specifying steel bar grating.

(888) 499-8494

sales@interstategratings.com